

?????? MQTT

??????????

- [Описание протокола сообщений MQTT v1.0](#)

????????? ????????????

???????????? MQTT v1.0

Publish

/LWT

device/umni-838a74/lwt

```
{  
  "state": "online"  
}
```

```
{  
  "state": "offline"  
}
```

/PONG

device/umni-838a74/pong

```
{  
  "ping": "pong"  
}
```

/REGISTER

device/umni-838a74/register

```
{  
  "hostname": "umni-838a74",  
  "capabilities": [  
    "ethernet",  
    "sdcard",  
    ...  
  ],  
  "networks": [  
    ...  
  ]  
}
```

```
{
  "name": "ethernet",
  "ip": "192.168.88.122",
  "mask": "255.255.252.0",
  "gw": "192.168.88.9",
  "active": true
}
],
"heap": {
  "total": 383104,
  "free": 191552,
  "min": 178628
},
"device_type": "generic"
}
```

/CONFIG (onewire)

device/umni-838a74/config

```
{
  "key": "onewire",
  "config": {
    "sensors": [
      {
        "sn": "F7062454B2EE5528",
        "label": "Sensor F7062454B2EE5528",
        "active": true
      }
    ]
  }
}
```

/CONFIG (rf433)

device/umni-838a74/config

```
{
  "key": "rf433",
  "config": {
    "devices": []
  }
}
```

```
}  
}
```

/CONFIG (ntc)

device/umni-838a74/config

```
{  
  "key": "ntc",  
  "config": {  
    "channels": [  
      {  
        "id": 0,  
        "label": "NTC Sensor 1",  
        "active": true  
      },  
      {  
        "id": 1,  
        "label": "NTC Sensor 2",  
        "active": true  
      }  
    ]  
  }  
}
```

/CONFIG (adc)

device/umni-838a74/config

```
{  
  "key": "adc",  
  "config": {  
    "channels": [  
      {  
        "id": 0,  
        "label": "ADC Input 1",  
        "active": true  
      },  
      {  
        "id": 1,  
        "label": "ADC Input 2",  
        "active": true  
      }  
    ]  
  }  
}
```

```
        "active":true
    }
]
}
}
```

/CONFIG (inputs)

device/umni-838a74/config

```
{
  "key": "inputs",
  "config": {
    "inputs": [
      {
        "config_index": 1,
        "port_index": 1,
        "label": "Input 1 (port 1)",
        "active": true
      },
      ...
    ],
  }
}
```

/SENSORS (onewire)

device/umni-838a74/sensors

```
{
  "category": "onewire",
  "capability": "onewire",
  "value": 28.25,
  "serial": "F7062454B2EE5528"
}
```

/SENSORS (ntc)

device/umni-838a74/sensors

```
{
  "category": "ntc",
  "capability": "ntc1",
  "value": 27.906805038452148,
  "serial": null
}
```

/SENSORS (adc)

device/umni-838a74/sensors

```
{
  "category": "adc",
  "capability": "ai1",
  "value": 27.906805038452148,
  "serial": null
}
```

/SENSORS (outputs)

device/umni-838a74/sensors:

```
{
  "category": "outputs",
  "capability": "out2",
  "value": 1,
  "serial": null
}
```

/SENSORS (inputs)

device/umni-838a74/sensors:

```
{
  "category": "inputs",
  "capability": "inp4",
  "value": 0,
  "serial": null
}
```

/SENSORS (outputs)

device/umni-838a74/sensors:

```
{
  "key": "dio",
  "config": {
    "outputs": [
      {
        "config_index": 1,
        "port_index": 0,
        "label": "Output 1 (port 0)",
        "active": true,
        "default_state": 0
      },
      ...
    ]
  }
}
```

Subscribe

Ping

device/umni-838a74/ping

Payload ""